



- S1 Tumbler switch for vacuum motor
- S2 Switch for pump
- C1 Capacitor
- D1 Diode
- P Vacuum motor NDS-X
- SM Vacuum motor

# TW 350

## Wiring plan

As at: 10/08/21 Time:06:34

<b>Pos.</b>	<b>Description</b>	<b>Reference</b>
C1	Capacitor	
D	Diode	
D1	Diode	
P	Vacuum motor NDS-X	P...809
S1	Tumbler switch for vacuum motor	
S2	Switch for pump	
SM	Vacuum motor	P...870B